

Volume Solids and Spreading Rate

5.3.1

What Is Volume Solids?

All paints are made up of resin, pigments, additives (such as stabilisers, anti-foams and thickeners) and solvent. After the paint is applied, the solvent evaporates, leaving only the dry **SOLIDS** in the form of a continuous coating.



The solids can be expressed as a volume percentage of the entire volume of the can of paint. For example, if solvent takes up half the paint volume, then one can say that the paint is 50% solids. One can therefore expect that if a wet coat of paint is applied to a wet film thickness of 100 microns, the dry paint film will be 50 microns in thickness.

$$\% \text{ Volume Solids} = \frac{\text{Dry Film Thickness} \times 100}{\text{Wet Film Thickness}}$$

So, for a product that, when applied, had a measured **wet film thickness** of **100 microns**, and after the solvent had evaporated, left a **dry film** of **50 microns**, the volume solids would be:

$$\% \text{ Volume Solids} = \frac{50 \times 100}{100} = 50\% \quad \checkmark$$

We rarely need to calculate volume solids, though, as it is quoted on the product data sheet.

The volume solids value can help you calculate theoretical spreading rates, the wet film thickness to deliver the required dry film thickness and corrected wet and dry film thicknesses when thinned by a known amount of solvent.

Relationship Between Spreading Rate And Volume Solids

If you have the volume solids value, and know what dry film thickness you require, then you can calculate what the wet film thickness needs to be using some simple mathematical formulae:

$$\text{Wet Film Thickness} = \frac{\text{Dry Film Thickness} \times 100}{\% \text{ Volume Solids}}$$

$$\text{Spreading Rate (m}^2\text{/litre)} = \frac{\% \text{ Volume Solids} \times 10}{\text{DFT Required}}$$

Example

A section of steel needs to be coated in **125 microns** (DFT) of **Duremax[®] GPE**, which is **71% solids**. What is the **wet film thickness** required?

$$\text{Wet Film Thickness} = \frac{125 \text{ microns} \times 100}{71} = 176 \text{ microns}$$

To achieve this wet film thickness, what should the **spreading rate** be (in square metres per litre)?

$$\text{Spreading Rate (m}^2\text{/litre)} = \frac{\% \text{ Volume Solids} \times 10}{\text{DFT Required}} = \frac{71 \times 10}{125} = 5.7 \text{ m}^2\text{/litre}$$

Volume Solids and Spreading Rate

5.3.1

Effect Of Thinner On Volume Solids And Wet Film Thickness

We often need to thin a product down to apply it more easily in certain conditions. If we know the volume solids of a product and the dry film thickness required, and add a precisely known amount of thinner, the wet film thickness and the spreading rate required can be calculated thus:

$$\text{Corrected \% Volume Solids} = \frac{\% \text{ Volume Solids} \times 100}{(100 + \% \text{ Thinner added})}$$

$$\text{Corrected Wet Film Thickness} = \frac{\text{Dry film thickness} \times (100 + \% \text{ Thinner added})}{\% \text{ Volume solids}}$$

Example:

If we are to apply **Duremax[®] GPE**, with a Volume Solids of **71%**, to a dry film thickness of **125 microns** after adding **5% thinner**:

$$\text{Corrected \% Volume Solids} = \frac{\% \text{ Volume Solids} \times 100}{(100 + \% \text{ Thinner added})} = \frac{71 \times 100}{100 + 5} = 67.6 \%$$

$$\text{Wet Film Thickness} = \frac{\text{Dry film thickness} \times 100}{\text{Corrected \% Volume Solids}} = \frac{125 \times 100}{67.6} = 185 \text{ microns}$$

$$\text{Spreading Rate (m}^2\text{/litre)} = \frac{\text{Corrected \% Volume Solids} \times 10}{\text{DFT Required}} = \frac{67.6 \times 10}{125} = 5.4 \text{ m}^2\text{/litre}$$

Converting From Theoretical To Practical Spreading Rate

Theoretical spreading rates are based on the volume solids of each product and offer a factual starting point from which to estimate practical spreading rates. The amount necessary to reduce theoretical rate to arrive at practical rate is best determined by experience with similar jobs, since it depends on:

1. Type of object being painted.
2. Material needed to fill in the surface depressions caused by pitting and by abrasive blasting.
3. Excessive film thickness over the required minimum.
4. Material losses due to: wastage in pots, hoses, brush, rollers, overspray, wind losses, etc.
5. Skill and experience of spray painter and painters.
6. Porosity of surfaces.

Practical spreading rates may be estimated using the following rule of thumb:

- Application by brush or roller 10 - 15% reduction in theoretical spreading rate
- Application by airless spray 10 - 15% reduction in theoretical spreading rate
- Application by conventional spray 40 - 50% reduction in theoretical spreading rate

Estimation of Paint Required

$$\text{Volume of paint (litres)} = \frac{10 \times \text{Area (sqm)} \times \text{Dry film thickness}}$$

Volume Solids and Spreading Rate

5.3.1

% Volume Solids x (100 – % Wastage)

Wet Film Thickness (microns)

| Volume Solids (%) | Specified Dry Film Thickness (microns) | | | | | | | | | | | | | | | | |
|-------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|
| | 20 | 25 | 30 | 35 | 40 | 50 | 60 | 75 | 90 | 100 | 125 | 200 | 250 | 300 | 350 | 500 | 1000 |
| 10 | 200 | 250 | 300 | 350 | 400 | - | - | - | - | - | - | - | - | - | - | - | - |
| 15 | 133 | 166 | 200 | 233 | 266 | 333 | - | - | - | - | - | - | - | - | - | - | - |
| 20 | 100 | 125 | 150 | 175 | 200 | 250 | 300 | - | - | - | - | - | - | - | - | - | - |
| 25 | 80 | 100 | 120 | 140 | 160 | 200 | 240 | 300 | - | - | - | - | - | - | - | - | - |
| 30 | 66 | 83 | 100 | 117 | 133 | 166 | 200 | 250 | 300 | - | - | - | - | - | - | - | - |
| 35 | 57 | 71 | 85 | 100 | 114 | 142 | 171 | 214 | 257 | 285 | 357 | - | - | - | - | - | - |
| 40 | 50 | 62 | 75 | 87 | 100 | 125 | 150 | 187 | 225 | 250 | 312 | 500 | - | - | - | - | - |
| 45 | 44 | 55 | 66 | 77 | 88 | 111 | 133 | 166 | 200 | 222 | 277 | 444 | 555 | - | - | - | - |
| 50 | 40 | 50 | 60 | 70 | 80 | 100 | 120 | 150 | 180 | 200 | 250 | 400 | 500 | - | - | - | - |
| 55 | 36 | 45 | 54 | 63 | 72 | 90 | 109 | 136 | 163 | 181 | 227 | 363 | 454 | 545 | - | - | - |
| 60 | 30 | 41 | 50 | 58 | 66 | 83 | 100 | 125 | 150 | 166 | 208 | 333 | 416 | 500 | - | - | - |
| 65 | - | 38 | 46 | 53 | 61 | 76 | 100 | 115 | 138 | 153 | 192 | 307 | 384 | 461 | 538 | - | - |
| 70 | - | 35 | 42 | 50 | 57 | 71 | 85 | 107 | 128 | 142 | 178 | 285 | 357 | 428 | 500 | - | - |
| 75 | - | - | 40 | 46 | 53 | 66 | 80 | 100 | 120 | 133 | 166 | 266 | 333 | 400 | 466 | 666 | - |
| 80 | - | - | 37 | 43 | 50 | 62 | 75 | 93 | 112 | 125 | 156 | 250 | 312 | 375 | 437 | 625 | - |
| 85 | - | - | - | 41 | 47 | 58 | 70 | 88 | 105 | 117 | 147 | 235 | 294 | 352 | 411 | 588 | - |
| 90 | - | - | - | 38 | 44 | 55 | 66 | 83 | 100 | 111 | 138 | 222 | 277 | 333 | 388 | 555 | 1111 |
| 95 | - | - | - | - | 42 | 52 | 63 | 78 | 94 | 105 | 131 | 210 | 263 | 315 | 368 | 526 | 1052 |
| 100 | - | - | - | - | 40 | 50 | 60 | 75 | 90 | 100 | 125 | 200 | 250 | 300 | 350 | 500 | 1000 |

Theoretical Spreading Rate (m²/L)

| Dry Film Thickness (micron) | Volume Solids (%) | | | | | | | | | | | | | | | | |
|-----------------------------|-------------------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | 85 | 90 | 95 | 100 |
| 20 | 10.0 | 12.5 | 15.0 | 17.5 | 20.0 | 22.5 | 25.0 | 27.5 | 30.0 | 32.5 | 35.0 | 37.5 | 40.0 | 42.5 | 45.0 | 47.5 | 50.0 |
| 25 | 8.0 | 10.0 | 12.0 | 14.0 | 16.0 | 18.0 | 20.0 | 22.0 | 24.0 | 26.0 | 28.0 | 30.0 | 32.0 | 34.0 | 36.0 | 38.0 | 40.0 |
| 30 | 6.7 | 8.3 | 10.0 | 11.7 | 13.3 | 15.0 | 16.7 | 18.3 | 20.0 | 21.7 | 23.3 | 25.0 | 26.7 | 28.3 | 30.0 | 31.7 | 33.3 |
| 50 | 4.0 | 5.0 | 6.0 | 7.0 | 8.0 | 9.0 | 10.0 | 11.0 | 12.0 | 13.0 | 14.0 | 15.0 | 16.0 | 17.0 | 18.0 | 19.0 | 20.0 |
| 75 | 2.7 | 3.3 | 4.0 | 4.7 | 5.3 | 6.0 | 6.7 | 7.3 | 8.0 | 8.7 | 9.3 | 10.0 | 10.7 | 11.3 | 12.0 | 12.7 | 13.3 |
| 100 | 2.0 | 2.5 | 3.0 | 3.5 | 4.0 | 4.5 | 5.0 | 5.5 | 6.0 | 6.5 | 7.0 | 7.5 | 8.0 | 8.5 | 9.0 | 9.5 | 10.0 |
| 125 | 1.6 | 2.0 | 2.4 | 2.8 | 3.2 | 3.6 | 4.0 | 4.4 | 4.8 | 5.2 | 5.6 | 6.0 | 6.4 | 6.8 | 7.2 | 7.6 | 8.0 |
| 150 | 1.3 | 1.7 | 2.0 | 2.3 | 2.7 | 3.0 | 3.3 | 3.7 | 4.0 | 4.3 | 4.7 | 5.0 | 5.3 | 5.7 | 6.0 | 6.3 | 6.7 |
| 175 | 1.1 | 1.4 | 1.7 | 2.0 | 2.3 | 2.6 | 2.9 | 3.1 | 3.4 | 3.7 | 4.0 | 4.3 | 4.6 | 4.9 | 5.1 | 5.4 | 5.7 |
| 200 | 1.0 | 1.3 | 1.5 | 1.8 | 2.0 | 2.3 | 2.5 | 2.8 | 3.0 | 3.3 | 3.5 | 3.8 | 4.0 | 4.3 | 4.5 | 4.8 | 5.0 |
| 250 | 0.8 | 1.0 | 1.2 | 1.4 | 1.6 | 1.8 | 2.0 | 2.2 | 2.4 | 2.6 | 2.8 | 3.0 | 3.2 | 3.4 | 3.6 | 3.8 | 4.0 |
| 300 | 0.7 | 0.8 | 1.0 | 1.2 | 1.3 | 1.5 | 1.7 | 1.8 | 2.0 | 2.2 | 2.3 | 2.5 | 2.7 | 2.8 | 3.0 | 3.2 | 3.3 |
| 400 | 0.5 | 0.6 | 0.8 | 0.9 | 1.0 | 1.1 | 1.3 | 1.4 | 1.5 | 1.6 | 1.8 | 1.9 | 2.0 | 2.1 | 2.3 | 2.4 | 2.5 |
| 500 | 0.4 | 0.5 | 0.6 | 0.7 | 0.8 | 0.9 | 1.0 | 1.1 | 1.2 | 1.3 | 1.4 | 1.5 | 1.6 | 1.7 | 1.8 | 1.9 | 2.0 |

Volume Solids and Spreading Rate

5.3.1

Corrected Volume Solids After Thinning (%)

| Original Volume Solid (%) | Percentage Thinner Added (%) | | | | | | |
|---------------------------|------------------------------|------|----|------|----|----|----|
| | 5 | 10 | 15 | 20 | 25 | 33 | 50 |
| 15 | 14 | 13.6 | 13 | 12.5 | 12 | 11 | 10 |
| 20 | 19 | 18 | 17 | 16.7 | 16 | 15 | 13 |
| 25 | 24 | 23 | 22 | 21 | 20 | 19 | 17 |
| 30 | 29 | 27 | 26 | 25 | 24 | 23 | 20 |
| 35 | 33 | 32 | 30 | 29 | 28 | 26 | 23 |
| 40 | 38 | 36 | 35 | 33 | 32 | 30 | 27 |
| 45 | 43 | 41 | 39 | 37 | 36 | 34 | 30 |
| 50 | 48 | 45 | 43 | 42 | 40 | 38 | 33 |
| 55 | 52 | 50 | 48 | 46 | 44 | 41 | 37 |
| 60 | 57 | 55 | 52 | 50 | 48 | 45 | 40 |
| 65 | 62 | 59 | 56 | 54 | 52 | 49 | 43 |
| 70 | 67 | 64 | 61 | 58 | 56 | 53 | 47 |
| 75 | 71 | 68 | 65 | 62 | 60 | 56 | 50 |
| 80 | 76 | 73 | 70 | 67 | 64 | 60 | 53 |
| 85 | 81 | 77 | 74 | 71 | 68 | 64 | 57 |
| 90 | 86 | 82 | 78 | 75 | 72 | 68 | 60 |
| 95 | 90 | 86 | 83 | 79 | 76 | 71 | 63 |
| 100 | 95 | 91 | 87 | 83 | 80 | 75 | 67 |

For more information, please contact the Dulux Protective Coatings Technical Consultant in your state, or refer Dulux Protective Coatings Product Manual CD.